

Presperse Finished Products

635 Pierce Street • Somerset, NJ 08873 • Tel: (732) 356-5200 • www.presperse.com

Bare Max

(All Day Soothing Eye Shadow-MAX)

Formula #37-82-2, Date: 3/18/2010

WHAT IS IT?	Extended wear eye shadow in a neutral shade with natural active ingredients to maintain skin health.
HOW DO YOU USE IT?	Apply evenly over eyelid
WHO SHOULD USE IT?	Those seeking a long wear "one and done" application with a wash of color.
WHAT DOES IT DO?	Formulated to prevent creasing and "stay put" throughout the day. Shade is formulated to produce a neutral tone that could be worn everyday either alone or paired with complimentary shades.

Trade Name	INCI Name	Supplier	% W/W
PHASE A			
SERICITE PHN	Mica	Presperse, LLC	35.75
Zinc Stearate	Zinc Stearate	Chemtura	5.00
CHIFFONSIL P3-R	Silica	Presperse, LLC	5.00
SP-29 UVS	Bismuth Oxychloride (and) Mica (and) Silica	Presperse, LLC	5.00
MICROPOLY 1160S	Polyethylene	Presperse, LLC	2.75
OLEOSPERSE BLACK IRON OXIDE	Iron Oxide (and) Dimethicone	Presperse, LLC	0.25
OLEOSPERSE RED IRON OXIDE	Iron Oxide (and) Dimethicone	Presperse, LLC	0.75
OLEOSPERSE YELLOW IRON OXIDE	Iron Oxide (and) Dimethicone	Presperse, LLC	0.50
PHASE B			
BISMICA MAX MAUVE	Bismuth Oxychloride (and) Mica (and) Manganese Violet	Presperse, LLC	11.50
BISMICA MAX BROWN	Bismuth Oxychloride (and) Mica (and) Carmine	Presperse, LLC	4.00
BISMICA MAX DORADO	Bismuth Oxychloride (and) Mica (and) Ultramarine Blue	Presperse, LLC	11.50
PRESPEARL™ ULTRA RED	Mica (and) Titanium Dioxide	Presperse, LLC	5.00
PHASE C			
PERMETHYL® 284C	Polyisobutene & C15-19 Alkane (and) C12-14 Isoparaffin	Presperse, LLC	5.00
PERMETHYL 102A	Isoeicosine	Presperse, LLC	5.00
KALPARIANE®	Caprylic/ Capric Triglyceride (and) Alaria Esculenta Extract	Presperse, LLC	1.00
SUN ESSENCE HG CLOUDBERRY SEED EXTRACT	Rubus Chamaeromorus Seed Oil	Presperse, LLC	1.00
Euxyl PE 9010	Phenoxyethanol (and) Ethylhexylglycerin	Schülke	1.00

Presperse products appear in bold.
Formula #: 37-82-2, Date: 3/18/10



P R O C E D U R E

1. Combine Phase A in the order listed and pass through the pulverizer twice.
2. Drawdown powder phase and check for streaking. If needed, re-pulverize until color is evenly dispersed.
3. Add Phase B to Phase A.
4. Re-pulverize Phase AB until all ingredients are evenly dispersed.
5. Add Phase C and re-pulverize
6. Fill approximately 2.00 grams of powder into a 1" diameter pan at 500 psi.

INGREDIENT	FUNCTION
BISMICA MAX MAUVE, BROWN, DORADO	Colored pearl pigments with excellent wear properties and easy dispersability
CHIFFONSIL P3-R	Smooth, creamy application
KALPARIANE	Increases skin hydration prevent collagen and elastin degradation
MICROPOLY 1160S	Smooth, ball bearing effect provides easy application
OLEOSPERSE RED, YELLOW, BLACK IRON OXIDE	Hydrophobically treated pigments to extend wear
PERMETHYL 102A	Provides satiny feel to the skin
PERMETHYL 284C	Extends wear through film forming properties
PRESPEARL ULTRA RED	Pink pearlescence
SERICITE PHN	Cost effective, smooth, translucent, filler
SP-29 UVS	Enhances wear through superior adhesion
SUN ESSENCE HG CLOUDBERRY SEED EXTRACT	Offers a unique combination of energy and nutrition

S P E C I F I C A T I O N S	
APPEARANCE	Neutral nude eye shadow

PRESPERSE MAKES NO WARRANTY, EXPRESSED OR IMPLIED, OTHER THAN THOSE EXPRESSLY SET FORTH ABOVE, AND ALL OTHER EXPRESSED AND IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY EXPRESSLY DISCLAIMED BY PRESERSE. WITHOUT LIMITING THE GENERALITY OF THE FOREGOING, PRESERSE MAKES NO WARRANTIES, EXPRESSED OR IMPLIED, WITH RESPECT TO THE USE OR MISUSE OR REFORMULATION OF GOODS SOLD HEREUNDER ON OR WITH GOODS NOT SOLD BY PRESERSE. PRESERSE DOES NOT WARRANT FAVORABLE RESULTS FROM, AND ASSUMES NO LIABILITY IN CONNECTION WITH THE USE OF THE PRODUCTS SOLD HEREUNDER. THE PRODUCTS SOLD HEREUNDER ARE INTENDED FOR USE BY PERSONS HAVING TECHNICAL SKILL AND KNOWLEDGE, AT THEIR OWN DISCRETION AND RISK.

© 2010 Presperse, LLC. All rights reserved.

FORMULATION #: 37-82-2

DATE: 3/18/10

