

Presperse Finished Products

635 Pierce Street • Somerset, NJ 08873 • Tel: (732) 356-5200 • www.presperse.com

Brazen Bronze

(Intense Eye Shadow with BisMica MAX Pigments)

Formula #37-83-1, Date: 3/30/2010

WHAT IS IT?	High impact, high luster eye shadow
HOW DO YOU USE IT?	Apply evenly to primed eyelids.
WHO SHOULD USE IT?	Those bold enough to make a statement with their cosmetics.
WHAT DOES IT DO?	BISMICA MAX PIGMENTS add an intense color deposit, which is further enhanced by the excellent pigment wetting capabilities of PERMETHYL® 103A . MICROSILK 419 offers high slip allowing for easy application. SP-29 UVS enhances wear through its strong adhesion properties. BLUE SEAKALE SC® inhibits photo-aging and revitalizes the skin. EFADUO BLACK CURRANT SEED OIL soothes irritated skin and restores skin balance by supplying Omega-3 and other skin essential fatty acids.

Trade Name	INCI Name	Supplier	% W/W
PHASE A			
TALC MICRO ACE P-2	Talc	Presperse, LLC	29.50
Zinc Stearate	Zinc Stearate	Chemtura	5.00
MICROSILK 419	PTFE (and) Polyethylene	Presperse, LLC	3.00
SP-29 UVS	Bismuth Oxychloride (and) Mica (and) Silica	Presperse, LLC	6.00
OLEOSPERSE BLACK IRON OXIDE	Iron Oxide (and) Dimethicone	Presperse, LLC	1.75
OLEOSPERSE RED IRON OXIDE	Iron Oxide (and) Dimethicone	Presperse, LLC	2.00
OLEOSPERSE YELLOW IRON OXIDE	Iron Oxide (and) Dimethicone	Presperse, LLC	1.75
BISMICA MAX BROWN	Bismuth Oxychloride (and) Mica (and) Ultramarine Blue	Presperse, LLC	17.00
BISMICA MAX VIOLET	Bismuth Oxychloride (and) Mica (and) Manganese Violet	Presperse, LLC	17.00
PHASE B			
PERMETHYL 103A	Isotetracosane	Presperse, LLC	3.00
PERMETHYL 102 A	Isoeicosine	Presperse, LLC	5.00
BLUE SEAKALE SC	Caprylic/ Capric Triglyceride (and) Crambe Maritima Extract	Presperse, LLC	1.00
EFADUO BLACK CURRANT SEED OIL	Ribes Nigrum Seed Oil	Presperse, LLC	1.00
Euxyl PE 9010	Phenoxyethanol (and) Ethylhexylglycerin	Schülke	1.00
PHASE C			
PRESPERL™ ULTRA GOLD	Mica (and) Iron Oxide	Presperse, LLC	6.00

Presperse products appear in bold.

Formula #37-83-1, Date: 3/30/2010



P R O C E D U R E

1. Combine Phase A in the order listed and pass through the pulverizer twice.
2. Drawdown powder phase and check for streaking. If needed, re-pulverize until color is evenly dispersed.
3. Add Phase B to Phase A.
4. Re-pulverize Phase AB until all ingredients are evenly dispersed.
5. Add Phase C and re-pulverize
6. Fill approximately 2.00 grams of powder into a 1" diameter pan at 500 psi.

INGREDIENT	FUNCTION
BISMICA MAX BROWN, VIOLET	Intense color lay down with extended wear properties
BLUE SEAKALE SC	Skin revitalize, slows down photo-aging and chronic aging
EFADUO BLACK CURRANT SEED OIL	Rich in Omega-3 and skin essential vitamins to restore skin balance; reduces inflammation, and soothes irritated skin
MICROSILK 419	Slip modifier
OLEOSPERSE YELLOW, RED, BLACK IRON OXIDE	Hydrophobically treated pigments to extend wear
PERMETHYL 102A	Liquid binder/ pigment wetter
PERMETHYL 103A	Liquid binder/ pigment wetter
PRESPEARL ULTRA GOLD	Pearlescent gold pigment
SP-29 UVS	Provides good coverage and adhesion properties
TALC MICRO ACE P-2	Cost effective, smooth, creamy jet-milled powder

S P E C I F I C A T I O N S

APPEARANCE	Bronze pearlescent eye shadow
------------	-------------------------------

PRESPERSE MAKES NO WARRANTY, EXPRESSED OR IMPLIED, OTHER THAN THOSE EXPRESSLY SET FORTH ABOVE, AND ALL OTHER EXPRESSED AND IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY EXPRESSLY DISCLAIMED BY PRESERSE. WITHOUT LIMITING THE GENERALITY OF THE FOREGOING, PRESERSE MAKES NO WARRANTIES, EXPRESSED OR IMPLIED, WITH RESPECT TO THE USE OR MISUSE OR REFORMULATION OF GOODS SOLD HEREUNDER ON OR WITH GOODS NOT SOLD BY PRESERSE. PRESERSE DOES NOT WARRANT FAVORABLE RESULTS FROM, AND ASSUMES NO LIABILITY IN CONNECTION WITH THE USE OF THE PRODUCTS SOLD HEREUNDER. THE PRODUCTS SOLD HEREUNDER ARE INTENDED FOR USE BY PERSONS HAVING TECHNICAL SKILL AND KNOWLEDGE, AT THEIR OWN DISCRETION AND RISK.

© 2010 Presperse, LLC. All rights reserved.

FORMULATION #: 37-83-1

DATE: 3/30/10

