

Presperse Finished Products

635 Pierce Street • Somerset, NJ 08873 • Tel: (732) 356-5200 • www.presperse.com

Refresh

(Skin Balancing Tonic)

Formula #38-17-1, Date: 4/30/10

WHAT IS IT?	A toner which helps to minimize pores and removes excess oil and gently tightens the skin without irritation.
HOW DO YOU USE IT?	After cleansing skin, apply toner with a cotton ball and gently roll over face until all areas are covered. Avoid eye area.
WHO SHOULD USE IT?	Anyone who wants to keep their skin clean and fresh by removing excess oil and impurities which lead to blemishes or breakouts.
WHAT DOES IT DO?	PANADOXINE™ P has good efficacy in regulation of sebum production and in reduction of skin inflammation. This efficacy provides mid and long-term regulation for daily skin care. SEA MAYWEED® is a marine extract that provides anti-inflammatory and anti-redness properties for sensitive skin.

Trade Name	INCI Name	Supplier	% W/W
PHASE A			
Deionized Water	Water	N/A	80.85
Trilon BD	Disodium EDTA	BASF	0.10
Butylene Glycol	Butylene Glycol	Ruger	2.00
PANADOXINE P	Pyridoxine Cyclic Phosphate	Presperse, LLC	3.00
TEA 99%	Triethanolamine	Dow Chemical	2.00
SEA MAYWEED	Water (and) Tripleurospermum Maritima Extract	Presperse, LLC	1.00
Ethanol	Ethanol	N/A	10.00
Euxyl PE 9010	Phenoxyethanol (and) Ethylhexylglycerin	Schülke	1.00
FD&C Blue #1 (1% soln)	Blue 1	Hilton Davis	0.05

Presperse products appear in bold.
Formula #: 38-17-1, Date 4/30/10



P R O C E D U R E

1. In a main kettle add water and begin prop mixing with medium speed at 25 °C.
2. Continue to add each ingredient from Phase A in order to the main kettle. Mix well between additions.
3. Once all ingredients are in the main kettle, make sure it is uniform and clear.
4. Fill in appropriate containers.

INGREDIENT	FUNCTION
PANADOXINE P	Provides long-term regulation of oil and sensitive skin
SEA MAYWEED	Anti-inflammatory, anti-redness for sensitive skin

S P E C I F I C A T I O N S	
APPEARANCE	Liquid
pH	6.5 - 7

PRESPERSE MAKES NO WARRANTY, EXPRESSED OR IMPLIED, OTHER THAN THOSE EXPRESSLY SET FORTH ABOVE, AND ALL OTHER EXPRESSED AND IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY EXPRESSLY DISCLAIMED BY PRESPPERSE. WITHOUT LIMITING THE GENERALITY OF THE FOREGOING, PRESPPERSE MAKES NO WARRANTIES, EXPRESSED OR IMPLIED, WITH RESPECT TO THE USE OR MISUSE OR REFORMULATION OF GOODS SOLD HEREUNDER ON OR WITH GOODS NOT SOLD BY PRESPPERSE. PRESPPERSE DOES NOT WARRANT FAVORABLE RESULTS FROM, AND ASSUMES NO LIABILITY IN CONNECTION WITH THE USE OF THE PRODUCTS SOLD HEREUNDER. THE PRODUCTS SOLD HEREUNDER ARE INTENDED FOR USE BY PERSONS HAVING TECHNICAL SKILL AND KNOWLEDGE, AT THEIR OWN DISCRETION AND RISK.

© 2010 Presperse, LLC. All rights reserved.

FORMULATION #: 38-17-1

DATE: 4/30/10

