

Presperse Finished Products

635 Pierce Street • Somerset, NJ 08873 • Tel: (732) 356-5200 • www.presperse.com

Remove and Condition

(Make-Up Remover with Eye Lash Conditioner)

Formula #: 38-21-1, Date: 4/30/10

WHAT IS IT?	A make-up remover that conditions the eyelashes while removing eye make-up.
HOW DO YOU USE IT?	Rub the gel onto a cotton ball and gently wipe the eye make-up off with small dabbing motions. Use the cotton ball in a back-and-forth motion from root to tip on the eyelashes to remove any mascara.
WHO SHOULD USE IT?	Anyone who wants to condition, repair, and maintain hair strength of their eyelashes when removing eye makeup.
WHAT DOES IT DO?	ZILGEL® V V provides high moisturization and dehydration repair with great feel and wear properties. PELLICER™ L-30 repairs rough, damaged eyelashes and recovers skin elasticity with improved barrier function. The eyelashes are repaired, restructured and smoothed by BIO-RESTORER® .

Trade Name	INCI Name	Supplier	% W/W
PHASE A			
Deionized Water	Water	N/A	74.90
Trilon BD	Disodium EDTA	BASF	0.10
ZILGEL V V	Glycerin (and) Water (and) Sodium Polyacrylate	Presperse, LLC	20.00
Butylene Glycol	Butylene Glycol	Ruger	2.00
PELLICER L-30	Sodium Dilauramidoglutamide Lysine (and) Water	Presperse, LLC	1.00
BIO-RESTORER	Butylene Glycol (and) Water (and) Hypnea Musciformis	Presperse, LLC	1.00
Euxyl PE 9010	Phenoxyethanol (and) Ethylhexylglycerin	Schulke	1.00

Presperse products appear in bold.
Formula#: 38-21-1, Date: 4/30/10



P R O C E D U R E

1. In a main kettle add water and begin prop mixing with medium speed at 25 °C.
2. Continue to add each ingredient from Phase A in order, to the main kettle. Mix well between additions.
3. Once all ingredients are in the main kettle, make sure it is uniform and clear.
4. Fill in appropriate containers

INGREDIENT	FUNCTION
BIO-RESTORER	Repairs, restructures and smoothes the eye lashes
PELLICER L-30	Repairs rough, damaged eye lashes and recovers skin elasticity with improved barrier function
ZILGEL V V	High moisturization and hydration, non-drying gel

S P E C I F I C A T I O N S	
APPEARANCE	Clear viscous gel
pH	5.5 – 6
VISCOSITY	9,000 – 10,000 cps (spindle #63, 10 rpm @ 1 min)

PRESPERSE MAKES NO WARRANTY, EXPRESSED OR IMPLIED, OTHER THAN THOSE EXPRESSLY SET FORTH ABOVE, AND ALL OTHER EXPRESSED AND IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY EXPRESSLY DISCLAIMED BY PRESPESE. WITHOUT LIMITING THE GENERALITY OF THE FOREGOING, PRESPESE MAKES NO WARRANTIES, EXPRESSED OR IMPLIED, WITH RESPECT TO THE USE OR MISUSE OR REFORMULATION OF GOODS SOLD HEREUNDER ON OR WITH GOODS NOT SOLD BY PRESPESE. PRESPESE DOES NOT WARRANT FAVORABLE RESULTS FROM, AND ASSUMES NO LIABILITY IN CONNECTION WITH THE USE OF THE PRODUCTS SOLD HEREUNDER. THE PRODUCTS SOLD HEREUNDER ARE INTENDED FOR USE BY PERSONS HAVING TECHNICAL SKILL AND KNOWLEDGE, AT THEIR OWN DISCRETION AND RISK.

© 2010 Presperse, LLC. All rights reserved.

FORMULATION #: 38-21-1

DATE: 4/30/10

