

Presperse Finished Products

635 Pierce Street • Somerset, NJ 08873 • Tel: (732) 356-5200 • www.presperse.com

Slip Into This

(Sheer Gloss Stick)

Formula # 39-1-1, Date: 3/23/2010

WHAT IS IT?	A sheer gloss stick with active ingredients that provide and maintain healthy lips.
HOW DO YOU USE IT?	Apply to exfoliated lips.
WHO SHOULD USE IT?	Those looking for a comfortable, non-tacky, everyday sheer lip product to help repair dry, chapped lips.
WHAT DOES IT DO?	Improves skin moisturization by creating a barrier for TEWL through PERMETHYL® 104A . Protects the skin from UV damage through the anti-inflammatory natural active, ANTILEUKINE 6® . Promotes lip health through skin repair and wound healing by incorporating SHAJIO SEA BUCKTHORN BERRY OIL . Provides a sheer, glossy, subtle kiss of color.

Trade Name	INCI Name	Supplier	% W/W
PHASE A			
PERMETHYL 104A	Polyisobutene	Presperse, LLC	32.12
PERMETHYL 103A	Hydrogenated Polyisobutene	Presperse, LLC	30.13
Sweet Almond Oil	Prunus Amygdalus Dulcis	JEDwards Int.'l	9.00
MICROEASE 1132	Synthetic Wax (and) Microcrystalline Wax	Presperse, LLC	7.00
Performalene 400	Polyethylene	New Phase	3.00
Pelemol OP	Octyl Palmitate	Phoenix Chemical	5.80
PHASE B			
D&C Red #7 C19-011 (20% Dispersion in Eutanol G)	Red #7 (and) Octyldodecanol	In-house	0.50
Titanium Dioxide (20% Dispersion in Eutanol G)	Titanium Dioxide (and) Octyldodecanol	In-house	4.00
Black Iron Oxide (20% Dispersion in Eutanol G)	Iron Oxide (and) Octyldodecanol	In-house	0.10
BISMICA YELLOW MAX	Bismuth Oxychloride (and) Mica (and) Iron Oxide	Presperse, LLC	2.50
BISMICA DIAMOND 02	Bismuth Oxychloride (and) Mica	Presperse, LLC	0.50
PRESPEARL™ ULTRA RED	Mica (and) Titanium Dioxide	Presperse, LLC	1.00
PRESPEARL WHITE PEARL	Mica (and) Titanium Dioxide	Presperse, LLC	0.80
ROYAL PEARL PLUS UB-17	Polyurethane-16 (and) Silica	Presperse, LLC	1.00
PHASE C			
ANTILEUKINE 6	Caprylic/Capric Triglyceride (and) Laminaria Ochroleuca Extract	Presperse, LLC	1.00
SHAJIO SEA BUCKTHORN BERRY OIL	Hippophae Rhamnoides Oil	Presperse, LLC	1.00
SERICITE PHN	Mica	Presperse, LLC	0.30
Strawberry Fragrance	Fragrance	Bell Flavors and Fragrance	0.25

Presperse products appear in bold.
Formula #: 39-1-1, Date: 3/23/2010



P R O C E D U R E

1. Weigh all ingredients in Phase A into a main vessel.
2. Begin mixing and heating (Medium Speed, 90-95°C).
3. Add Phase B and mix until uniformly dispersed.
4. Once desired Shade is reached, add Phase C and mix until uniformly dispersed.
5. Cool Batch and pour into lipstick mold (80-85 °C)
6. Let mold set until solidified, scrap remnant product from top of mold. Chill for 20-30 minutes.
7. Remove product from mold and insert lipstick bullet into desired package.

INGREDIENT	FUNCTION
ANTILEUKINE 6	Excellent anti-inflammatory. Protects DNA against UVA and UVB damage.
BISMICA DIAMOND 02	Provides coverage and enhances color deposit
BISMICA YELLOW MAX	Provides intense yellow pigment
MICROEASE 1132	Provides structure and stability
PERMETHYL 103A	Provides superior gloss/shine with lightweight feel
PERMETHYL 104A	Provides excellent film formation, body and shine
PRESPEARL ULTRA RED	Provides pink pearlescent effect
PRESPEARL WHITE PEARL	Provides white pearlescent effect
ROYAL PEARL PLUS UB-17	Provides lubricity and enhances glide
SERICITE PHN	Cost effective filler
SHAJIO SEA BUCKTHORN BERRY OIL	Promotes wound healing and skin repair. Enhances UV protection

S P E C I F I C A T I O N S	
APPEARANCE	Pale pink lip stick
STABILITY	Stable: 4 Weeks @ 50 °C

PRESPERSE MAKES NO WARRANTY, EXPRESSED OR IMPLIED, OTHER THAN THOSE EXPRESSLY SET FORTH ABOVE, AND ALL OTHER EXPRESSED AND IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY EXPRESSLY DISCLAIMED BY PRESPPERSE. WITHOUT LIMITING THE GENERALITY OF THE FOREGOING, PRESPPERSE MAKES NO WARRANTIES, EXPRESSED OR IMPLIED, WITH RESPECT TO THE USE OR MISUSE OR REFORMULATION OF GOODS SOLD HEREUNDER ON OR WITH GOODS NOT SOLD BY PRESPPERSE. PRESPPERSE DOES NOT WARRANT FAVORABLE RESULTS FROM, AND ASSUMES NO LIABILITY IN CONNECTION WITH THE USE OF THE PRODUCTS SOLD HEREUNDER. THE PRODUCTS SOLD HEREUNDER ARE INTENDED FOR USE BY PERSONS HAVING TECHNICAL SKILL AND KNOWLEDGE, AT THEIR OWN DISCRETION AND RISK.

© 2010 Presperse, LLC. All rights reserved.

FORMULATION #: 39-1-1

DATE: 3/23/2010

