

# Presperse Finished Products

## Fill Me In

(Wrinkle Treatment)

Formula #: 35-31-3

WHAT IS IT?	W/O wrinkle correcting treatment lotion utilizing <b>PRESPERSE OPTICAL MODIFIER</b> for instant light diffusing effects, while <b>Si CLONE® TD-150</b> offers sun protection benefits. It also contains a Natural <b>MARINE ACTIVE</b> for longer-term Anti-Aging benefits.
HOW DO YOU USE IT?	Apply a small amount of product onto wrinkle-prone areas around the eyes, mouth and on the forehead. Smooth into a fine layer, spreading excess product onto other problematic areas.
WHO SHOULD USE IT?	Anyone seeking immediate wrinkle filling action to diminish the look of fine lines and wrinkles.
WHAT DOES IT DO?	<b>GANZPEARL GMP-0820</b> instantly reduces the appearance of fine lines by "filling in" and camouflaging the wrinkles through its soft focus effect, skin tone is immediately more even and younger in appearance. The <b>Si CLONE® TD-150</b> provides excellent sun protection from the damaging effects of UVB and UVA sunrays. Marine Active <b>SEA MAYWEED</b> works to provide long term anti-aging benefits through soothing and treating inflammation of skin.
WHAT'S IN IT?	Water (Aqua), C18-21 Alkane (and) Polyisobutene, C12-14 Isoparaffin (and) C18-21 Alkane, Acrylates Crosspolymer, Isododecane, Ethylene/Propylene/Styrene, Butylene/Ethylene/Styrene Copolymer, Polyurethane-16, Oxidized Polyethylene, PTFE, Lauryl PEG/PPG-19/18 Methicone, Cetyl PEG/PPG-10/11 Dimethicone, Phenoxyethanol, Ethylhexylglycerin, Tripleurospermum Maritime Extract, Sodium Chloride, Sodium Cocamidopropyl PG-Dimonium Chloride Phosphate.

Trade Name	INCI Name	Supplier	% W/W
<b>PHASE A</b>			
<b>PERMETHYL® 296C</b>	C12-14 Isoparaffin (and) C18-21 Alkane	<b>Presperse, LLC</b>	5.00
VERSAGEL MD1600	Isododecane (and) Ethylene/ Propylene/Styrene (and) Butylene/Ethylene/Styrene Copolymer	Penreco	7.50
FORMULATION AID 5200	Lauryl PEG/PPG-19/18 Methicone	Dow Corning	2.00
ABIL EM-90	Cetyl PEG/PPG-10/11 Dimethicone	Degussa	1.00
<b>PHASE B</b>			
<b>Si CLONE® TD-150</b>	Titanium Dioxide (and) C13-16 Isoparaffin (and) C12-14 Isoparaffin (and) C13-15 Alkane (and) Aluminum Hydroxide (and) Isostearic Acid (and) C18-21 Alkane	<b>Presperse, LLC</b>	12.00
<b>GANZPEARL GMP-0820</b>	Acrylates Crosspolymer	<b>Presperse, LLC</b>	10.00



<b>PERMETHYL® 246C</b>	C18-21 Alkane (and) Polyisobutene	<b>Presperse, LLC</b>	12.00
<b>PERMETHYL® 296C</b>	C12-14 Isoparaffin (and) C18-21 Alkane	<b>Presperse, LLC</b>	6.00
<b>PHASE C</b>			
<b>MICROPOLY 210</b>	Oxidized Polyethylene	<b>Presperse, LLC</b>	3.00
<b>MiCROSLIP 519</b>	PTFE	<b>Presperse, LLC</b>	2.00
<b>ROYAL PEARL UB17</b>	Polyurethane-16	<b>Presperse, LLC</b>	5.00
<b>PHASE D</b>			
DEIONIZED WATER	Water	N/A	31.00
<b>SEA MAYWEED SC</b>	Water (and) Tripleurospermum Maritime Extract	<b>Presperse, LLC</b>	1.00
SODIUM CHLORIDE USP	Sodium Chloride	N/A	0.75
PHOENOTAININE C-35	Sodium Cocamidopropyl PG-Dimonium Chloride Phosphate	Phoenix Chemical	0.75
EUXYL PE 9010	Phenoxyethanol (and) Ethylhexylglycerin	Schülke	1.00

Presperse products appear in bold.  
Formula #: 35-31-3 Date: 4/7/09

## P R O C E D U R E

1. Combine Phase A in the order listed with medium prop mixing at 20-25 °C. Mix until uniform (1-2 min).
2. Pre-disperse Phase B for best results. Combine Phase B and mix with a high shear mixer and homogenize until uniform at 20-25 °C.
3. Add Phase B to Phase A and mix with a high shear mixer at medium speed until homogenous (2-3 min) at 20-25 °C.
4. Add Phase C to Phase AB and mix until homogenous.
5. Combine Phase D in order listed with medium prop mixing at 20-25 °C. Mix until uniform (2-3 min).
6. Add Phase D to Phase ABC slowly and mix with a high shear mixer. Mix for 3-4 minutes at high speed, high shear at 20-25 °C. Transfer to closed container.

INGREDIENT	FUNCTION
<b>Si CLONE® TD-150</b>	Micronized Titanium Dioxide dispersion with excellent transparency and UV shielding.
<b>GANZPEARL GMP-0820</b>	Optical Modifier
<b>PERMETHYL® 246C</b>	Deeply moisturizing, film former
<b>PERMETHYL® 296C</b>	Moisturizing, skin brightener
<b>ROYAL PEARL UB17</b>	Offers creamy and luxurious after-feel to formula
<b>MICROPOLY 210</b>	Excellent binder and bulking agent, creamy feel
<b>MICROSLIP 519</b>	Smooth, creamy feel, high lubricity
<b>SEA MAYWEED SC</b>	Soothing, relaxing, decreases expression lines

## S P E C I F I C A T I O N S

APPEARANCE (@25C)	White, opaque, semi-solid
VISCOSITY (@25C)	15,000-30,000 cps (#6,10rpm, 1 min.)

PRESPERSE MAKES NO WARRANTY, EXPRESSED OR IMPLIED, OTHER THAN THOSE EXPRESSLY SET FORTH ABOVE, AND ALL OTHER EXPRESSED AND IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY EXPRESSLY DISCLAIMED BY PRESPPERSE. WITHOUT LIMITING THE GENERALITY OF THE FOREGOING, PRESPPERSE MAKES NO WARRANTIES, EXPRESSED OR IMPLIED, WITH RESPECT TO THE USE OR MISUSE OR REFORMULATION OF GOODS SOLD HEREUNDER ON OR WITH GOODS NOT SOLD BY PRESPPERSE. PRESPPERSE DOES NOT WARRANT FAVORABLE RESULTS FROM, AND ASSUMES NO LIABILITY IN CONNECTION WITH THE USE OF THE PRODUCTS SOLD HEREUNDER. THE PRODUCTS SOLD HEREUNDER ARE INTENDED FOR USE BY PERSONS HAVING TECHNICAL SKILL AND KNOWLEDGE, AT THEIR OWN DISCRETION AND RISK.

© 2009 Presperse, LLC. All rights reserved.

FORMULATION #: 35-31-3

DATE: 4/7/09

**PRESPPERSE**

635 Pierce Street, Somerset, NJ 08873 / Tel: (732) 356-5200 / Fax: (732) 356-3533 / Web: [presperse.com](http://presperse.com) © 2009 All Rights Reserved 05/09