

# Presperse Finished Products

635 Pierce Street • Somerset, NJ 08873 • Tel: (732) 356-5200 • www.presperse.com

## True Lies

Formula #: 32-24-1, Date: 4/06/08

WHAT IS IT?	Un-pigmented, W/O Wrinkle Eraser lotion utilizing <b>PRESPERSE OPTICAL MODIFIERS</b> for instant light diffusing effects and <b>ACTIVE PEPTIDES</b> for longer-term Anti-Aging benefits.
HOW DO YOU USE IT?	Apply a dime-size amount onto applicator and gently dab evenly over the face until a desired coverage is achieved. Also ideal as a spot treatment around the problematic eye and lip areas such as crow's feet and laugh lines.
WHO SHOULD USE IT?	Anyone seeking for immediate and long-term wrinkle erasing performance into one convenient package. Those seeking a natural looking coverage without the masking effect of make-up.
WHAT DOES IT DO?	Optical diffusers <b>GANZPEARL GMP-0820</b> and <b>LUXSIL</b> instantly reduces the appearance of fine lines and wrinkles while <b>SP-29 UVS</b> gives the skin brightening benefits. Skin tone is immediately more even and younger in appearance. Active <b>PEPTIDES</b> work to provide long term anti-aging benefits by treating and minimizing the occurrence of fine lines and wrinkles.
WHAT'S IN IT?	Water (Aqua), Acrylates Crosspolymer, Isohexadecane, Isododecane, C15-19 Alkane, Lauryl PEG/PPG-19/18 Methicone, Calcium Aluminum Borosilicate, Ethylene/Propylene/Styrene, Butylene/Ethylene/Styrene Copolymer, Fructan, Bismuth Oxychloride, Silica, Mica, Cetyl PEG/PPG-10/11 Dimethicone, Glycerin, Palmitoyl Tripeptide, Palmitoyl Tetrapeptide-3, Sodium Cocamidopropyl PG-Dimonium Chloride Phosphate, Dimethicone, C12-14 Isoparaffin, Polyisobutene, Butylene Glycol, Sodium Chloride, Phenoxyethanol, Ethylhexylglycerin

Trade Name	INCI Name	Supplier	% W/W
<b>PHASE A</b>			
<b>Permethyl 101A</b>	Isohexadecane	<b>Presperse, LLC</b>	12.70
<b>Permethyl 284C</b>	C15-19 Alkane (and) C12-14 Isoparaffin (and) Polyisobutene	<b>Presperse, LLC</b>	4.00
Versagel MD1600	Isododecane (and) Ethylene/ Propylene/Styrene (and) Butylene/Ethylene/Styrene Copolymer	Penreco	7.50
Formulation Aid 5200	Lauryl PEG/PPG-19/18 Methicone	Dow Corning	2.00
Abil EM-90	Cetyl PEG/PPG-10/11 Dimethicone	Degussa	1.00
<b>PHASE B</b>			
<b>Ganzpearl GMP-0820</b>	Acrylates Crosspolymer	<b>Presperse, LLC</b>	12.00
<b>SP- 29 UVS</b>	Bismuth Oxychloride (and) Mica (and) Silica	<b>Presperse, LLC</b>	3.00
<b>Luxsil</b>	Calcium Aluminum Borosilicate	<b>Presperse, LLC</b>	2.00
<b>PHASE C</b>			
Deionized Water	Water	N/A	44.30
<b>Peptide 8803</b>	Glycerin (and) Palmitoyl Oligopeptide	<b>Presperse, LLC</b>	3.0
<b>Peptide 8804</b>	Glycerin (and) Palmitoyl Tetrapeptide-3	<b>Presperse, LLC</b>	1.0
<b>Fructan</b>	Water (and) Butylene Glycol (and) Fructan	<b>Presperse, LLC</b>	5.00
Sodium Chloride USP	Sodium Chloride	N/A	0.75
Phenotaine C-35	Sodium Cocamidopropyl PG-Dimonium Chloride Phosphate	Phoenix Chemical	0.75
Euxyl PE 9010	Phenoxyethanol (and) Ethylhexylglycerin	Schülke	1.00

Presperse products appear in bold.

Formula #: 32-12-1, Date: 4/06/08



## P R O C E D U R E

1. Combine Phase A in the order listed with medium prop mixing at 20-25C. Mix until uniform (1-2 min).
2. Combine Phase B with a dry blender until uniform at 20-25C.
3. Add phase B to Phase A and mix with a high shear mixer at medium speed until homogenous (2-3 min) at 20-25C.
4. Combine Phase C in order listed with medium prop mixing at 20-25C. Mix until uniform (2-3 min).
5. Add Phase C to Phase AB slowly with slow prop mixing at 20-25C. Mix at low speed for 1 minute, then transfer to high shear mixer. Mix for 3-4 minutes at high speed, high shear at 20-25C. Transfer to closed container.

INGREDIENT	FUNCTION
GanzPearl GMP-0820	Optical Modifier
SP-29 UVS	Creamy feel, skin brightener
Luxsil	Optical Modifier
Permethyl 101A	Imparts a light silky feel on skin, highly emollient
Permethyl 284C	Deeply moisturizing, Film former
Fructan	Moisturizing, Humectant
Peptide 8803	Skin suppleness, tension, collagen stimulation, firmness.
Peptide 8804	Cytokine balance, tonicity, firmness.

## S P E C I F I C A T I O N S

APPEARANCE (@25C)	White, opaque, semi-solid
VISCOSITY (@25C)	15,000-30,000 cps (#6, 10rpm, 1 min.)

PRESPERSE MAKES NO WARRANTY, EXPRESSED OR IMPLIED, OTHER THAN THOSE EXPRESSLY SET FORTH ABOVE, AND ALL OTHER EXPRESSED AND IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY EXPRESSLY DISCLAIMED BY PRESPPERSE. WITHOUT LIMITING THE GENERALITY OF THE FOREGOING, PRESPPERSE MAKES NO WARRANTIES, EXPRESSED OR IMPLIED, WITH RESPECT TO THE USE OR MISUSE OR REFORMULATION OF GOODS SOLD HEREUNDER ON OR WITH GOODS NOT SOLD BY PRESPPERSE. PRESPPERSE DOES NOT WARRANT FAVORABLE RESULTS FROM, AND ASSUMES NO LIABILITY IN CONNECTION WITH THE USE OF THE PRODUCTS SOLD HEREUNDER. THE PRODUCTS SOLD HEREUNDER ARE INTENDED FOR USE BY PERSONS HAVING TECHNICAL SKILL AND KNOWLEDGE, AT THEIR OWN DISCRETION AND RISK.

© 2008 Presperse, LLC. All rights reserved.

**FORMULATION #: 32-24-1**

**DATE: 4/06/08**

